


# T80 FLEX



**Agglomerated cork and recycled EVA and PU foams underlayment for impact noise and thermal insulation. Excellent compensation for uneven floors**



## KEY FEATURES

- ▶ Excellent acoustic insulation.
- ▶ Good load absorption capacity.
- ▶ The most versatile underlayment with high durability and good performance.
- ▶ Anti-slip underlayment.
- ▶ Tested according to MMFA/EPLF minimum requirements group 1 and 2.

## PHYSICAL AND MECHANICAL PROPERTIES

Specific Weight (kg/m <sup>3</sup>   lb/ft <sup>3</sup> ) <sup>ⓐ</sup>	VB Class I	490–570   30–36
	VB Class III	250–300   15–18
Tensile Strength (kPa   Psi) <sup>ⓐ</sup>	VB Class I	> 200   > 29
	VB Class III	250   29
Compression at 0.7MPa (%) <sup>ⓐ</sup>		15–40
Recovery after 0.7MPa (%) <sup>ⓐ</sup>		> 60

ⓐ ISO 7322

## TECHNICAL PROPERTIES

Flooring		Laminated	Laminated
Thickness	mm	2.0	2.0
Thermal Resistance (TR) <sup>ⓐ</sup>	m <sup>2</sup> ·K/W   hr·ft <sup>2</sup> ·°F/BTU	0.031   0.0054	0.050   0.0088

## Floor Durability

Punctual Conformability (PC)	mm   in	> 1.3   > 0.051	> 1.3   > 0.051
Compressive Strength (CS)	kPa   Psi	> 300   > 43	400   43
Compressive Creep (CC)	kPa   Psi	> 90   > 13	> 90   > 13
Vapour Barrier		○	●

ⓐ Suitable for underfloor heating and cooling ● Yes ○ No

## THERMAL INSULATION

Thermal Conductivity (W/mK) ① 0.0637

Thermal Resistance (m<sup>2</sup>·K/W | hr·ft<sup>2</sup>·°F/BTU) 0.031 | 0.0054

① EN 8301

## ACOUSTICAL RESULTS


Flooring Laminate floor

Thickness (mm) 2

$\Delta L_w$  (dB) ① 20

① ISO 10140-3 and ISO 717-2

Reduction of impact noise



—  $L_{n,r,0}$  (dB) —  $L_{n,r}$  (dB) — Adjusted refer curve (dB)


$L_{n,r,0}$  Normalized impact sound pressure level of the Lab reference floor.

$L_{n,r}$  Normalized impact sound pressure level of the reference floor with the floor covering under test.

$\Delta L_w$  Impact sound pressure level reduction index of the covering under test, on a normalized floor.

The results are based on tests made with an artificial source under laboratory conditions (engineering method).


## TEST APPARATUS ( $\Delta L_w$ )



- ① Laminate floor
- ② Underlayment Acousticork T80
- ③ Concrete slab with 140 mm thickness


## PHYSICAL AND MECHANICAL PROPERTIES

Creep deflection @ 90 kPa (% of start height)



## INSTALLATION


### GLUED FLOORS



- ① Reinforced concrete slab
- ② Adhesive
- ③ Acousticork T80
- ④ Floor covering composed by wood

\*Product images and illustrations are for illustrative purposes only.

### NON GLUED FLOORS



- ① Reinforced concrete slab
- ② Acousticork T80
- ③ Vapour barrier
- ④ Non-glued laminated pavement

\*Product images and illustrations are for illustrative purposes only.

## GENERAL INSTALLATION INSTRUCTIONS (WITH AND WITHOUT GLUE)

The following installation instructions are recommended by Amorim Cork Solutions, and are not intended to be a definitive project specification. They should be interpreted and applied taking into account the recommendations of the manufacturers of the flooring to be installed, as well as the manufacturers of the glue, should this be necessary.

### Preparation of the subfloor

The subfloor must be level, dry, clean and in good structural conditions. A floor is considered level if the deviation height is less than 2mm over a distance of 2.5 linear meters. Deviations above this value must be leveled out before underlayment installation.

The humidity content of the concrete substrate must not exceed 2.5 % (MC) by weight. Any moisture problems need to be solved before installation. New concrete slabs need to cure for at least 120 days before installation.

The environmental conditions during the installation should be: temperature >10°C and humidity <75%

### Installation of the moisture barrier for floating installation

For floating floors you must first install a moisture barrier across the entire area of the room to minimize the risk of possible damage caused by rising damp, and then install the underlayment. The barrier must be installed directly onto the surface of the subfloor, in the opposite direction you plan to install the final floor to reduce seams. This moisture barrier should have a minimum sd-value of 75 m. It should be installed following the outline of the enclosing wall, to a height of at least 30 mm and with a minimum overlap of 100mm using a suitable tape to seal seams. After finishing, the barrier must cover the entire subfloor area without any gaps. Never mechanically secure the barrier with screws, nails or staples as this may compromise its effectiveness.


### Installation of the underlayment

Place one roll of the underlayment parallel to the wall and in the opposite direction you plan to install the final floor to reduce seams. Cut the underlayment material roll to the desired length and install it directly, covering the entire surface of the room. The underlayment must cover the entire area without any gaps, and be securely joined using duct tape. Never mechanically secure the underlayment with screws, nails or staples as this may compromise its effectiveness. Install the flooring perpendicularly to the underlayment. Always follow the flooring manufacturer's recommended installation instructions.



### Glued down installation

Before installing the underlayment, apply the glue and make sure that the surface has been treated to prevent moisture. The installation of a moisture barrier is not necessary. After applying the glue, cut the underlayment material roll to the desired length and install it directly, covering the entire surface. The underlayment must cover the entire area without any gaps, and be securely joined using duct tape. Never mechanically secure the underlayment with screws, nails or staples as this may compromise its effectiveness. Apply glue on the underlayment and install the flooring perpendicularly to the underlayment. Always follow the flooring manufacturer's recommended installation instructions.



**APPLICATION PROCESS · FLOATING FLOOR · NON-VAPOR BARRIER UNDERLAYMENT**





These are all the materials needed to install the underlayment.




For the installation process, open the packaging 48 hours in advance and leave for acclimatization




Subfloor preparation: Make sure that the subfloor is leveled, dry, clean and in good structural conditions.




New concrete slabs must be left to cure for 120 days before installation.




The humidity content of the substrate is critical: it must not exceed 2.5% (MC).




Air temperature should be above 10°C and air humidity below 75%.




You must first install a moisture barrier across the entire area of the room. It should be installed following the outline of the enclosing wall.




Use a height of at least 30 mm and with a minimum overlap of 100mm using a sealing tape to seal the seams.




The barrier must be installed directly onto the surface of the subfloor. Use a sealing tape to seal the rows securely together.




The installation should be in the opposite direction you plan to install the underlayment to reduce seams, in the same direction of the final floor.




Never mechanically secure the barrier with screws, nails or staples, since this may undermine its effectiveness.




Leave a little space between the wall and the underlayment.




The underlayment should be installed in a perpendicular direction to the final floor, which should always be installed in the direction of natural light incidence in the room.




The underlayment must cover the entire area without any gaps nor overlaps.




To securely joined using sealing tape.




Never mechanically secure the underlayment with screws, nails or staples, since this may undermine its effectiveness.




Install the flooring in a perpendicular direction to the underlayment.



Cut off excess moisture barrier.




Always follow the flooring manufacturer's recommended installation instructions.





Total System.



## APPLICATION PROCESS · GLUED FLOOR





These are all the materials needed to install the underlayment.




For the installation process, open the packaging 48 hours in advance and leave for acclimatization




Subfloor preparation: Make sure that the subfloor is leveled, dry, clean and in good structural conditions.




New concrete slabs must be left to cure for 120 days before installation.




The humidity content of the substrate is critical: it must not exceed 2.5% (MC).




Air temperature should be above 10°C and air humidity below 75%.




Optional step: apply the glue using a trowel. The installation of a moisture barrier is not necessary.




Optional step: we recommend the use of an adequate glue for the flooring to be installed.




Install the underlayment directly on the adhesive, leave a space between the wall and the underlayment.




The underlayment should be installed in a perpendicular direction that you plan to install the final floor.




The underlay must cover the entire area without any gaps nor overlaps.




Use the paint roller to make sure the underlayment doesn't have any waves.




Never mechanically secure the underlayment with screws, nails or staples, since this may undermine its effectiveness.




Apply the same glue on the underlayment.



Install the flooring in a perpendicular direction to the underlayment, and let the whole floor dry completely before you start to use it.



Always follow the flooring manufacturer's recommended installation instructions.



Total System.



## TECHNICAL DATA SHEET T80 FLEX

The data provided in this Technical Data Sheet represents typical values. This information is not intended to be used as a purchasing specification and does not imply suitability for use in a specific application. Failure to select the proper product may result in either equipments damage or personal injury. Please contact Amorim Cork Solutions regarding specific application recommendations. Amorim Cork Solutions expressly disclaims all warranties, including any implied warranties or merchantability or of fitness for a particular purpose. Amorim Cork Solutions is not liable for any indirect special, incidental, consequential, or punitive damages as a result of using the information listed in this TDS. Any of its material specification sheets, its products or any future use or re-use of them by any person or entity. For contractual purposes, please request our Product Specifications Sheet (PDA).