

# Underlay PLUS ACOUSTIC

UNDERLAY FOR THERMAL AND ACOUSTIC INSULATION





Dimension 1×10 m



Thickness 2 mm

# TECHNICAL PROPERTIES



Reduction of impact noise



Reduction of footfall noise



Thermal resistance



Compensates for uneven floor



Protection from damage from falling objects



Load resistance



# **Material Description & Properties**

Agglomerated cork and recycled EVA and PU foams underlay for impact noise and thermal insulation. Excelent compensation for uneven floors.

#### **KEY FEATURES**

- Excellent acoustic insulation.
- Good load absorption capacity.
- The most versatile underlay with high durability and good performance.
- Anti-slip underlay.
- Tested according to MMFA/EPLF minimum requirements group 1 and 2.

# **TECHNICAL DATA**

TEST	REQUIREMENT	UNIT	RESULT
Punctual conformability (PC)	≥ 0,5	mm	≥ 1,3
Compressive strenght (CS)	≥ 200	kPa	≥ 200
Compressive creep (CC)	≥ 10	kPa	≥ 90
Impact sound (IS)	≥ 10	dB	20
Reflected walking sound (RW	S) –	%	TBD
Thermal Resistance (R)*	≤ 0,15	m²°C/W	0,031
Dynamic load (DL)	≥ 10 000	cycles	≥ 10 000

<sup>\*</sup> Suitable for underfloor heating and cooling

# THERMAL INSULATION

Thermal Conductivity (1)	0,0637 W/mK
Thermal Resistance	0,0314 m <sup>2</sup> °C/W


(1) EN 8301

# **ACOUSTICAL RESULTS**

Flooring	Laminate floor
Thickness (mm)	2
ΔLw (dB) <sup>(1)</sup>	20

(1) ISO 10140-3 and ISO 717-2

#### REDUCTION OF IMPACT NOISE



 $L_{n,r,0}$  — Normalized impact sound pressure level of the Lab reference floor.

 $L_{n,r}$  – Normalized impact sound pressure level of the reference floor with the floor covering under test.


 $\Delta L_w - \mbox{Impact}$  sound pressure level reduction index of the covering under test, on a normalized floor.

The results are based on test made with an artificial source under laboratory conditions (engineering method).


# TEST APPARATUS (ΔL<sub>w</sub>)




# PHYSICAL AND MECHANICAL PROPERTIES



# **APPLICATION SCHEMES**







Reinforced concrete slab



Adhesive



Underlay GO4CORK PLUS



Floor covering composed by wood



Perimeter insulation barrier



barrier

Non-glued laminated pavement

# **NEGATIVE CARBON BALANCE**

**Underlay Plus** has a negative carbon balance of -8,1 kg  $CO_2/m^{2*}$ , when considering the  $CO_2$  sequestration of the cork oak forest and the  $CO_2$  emissions associated with the industrial process.



Consumes up to 20x less energy than any PU Foam solutions\*\*

Up to **34x less** greenhouse gas emissions than any PU Foam solutions\*\*

- \* EY Study: Underlayment Go4Cork Carbon Footprint Analysis, 2021 (cradle to gate).
- \*\* These Amorim Cork Solutions conclusions (outside the scope of the EY study) were based on the ecoinvent version 3.5 database (2018) but have not been verified by a third party.

#### GENERAL INSTALLATION INSTRUCTIONS

#### GENERAL INSTALLATION INSTRUCTIONS (WITH AND WITHOUT GLUE)

The following installation instructions are recommended by Amorim Cork Solutions, and are not intended to be a definitive project specification. They should be interpreted and applied taking into account the recommendations of the manufacturers of the flooring to be installed, as well as the manufactures of the glue, should this be necessary.

#### 1. PREPARATION OF THE SUBFLOOR

- The subfloor must be level, dry, clean and in good structural conditions. A floor is considered level if the deviation height is less than 2mm over a distance of 2.5 linear meters. Deviations above this value must be leveled out before underlay installation.
- The humidity content of the concrete substrate must not exceed 2.5 % (MC) by weight. Any moisture problems need to be solved before installation. New concrete slabs need to cure for at least 120 days before installation.
- The environmental conditions during the installation should be: temperature  $>10^{\circ}\text{C}$  and humidity <75%

#### 2. INSTALLATION OF THE MOISTURE BARRIER

For floating floors you must first install a moisture barrier across the entire area of the room to minimize the risk of possible damage caused by rising damp, and then install the underlay. The barrier must be installed directly onto the surface of the subfloor, in the opposite direction you plan to install the final floor to reduce seams. This moisture barrier should have a minimum sd-value of 75 m. It should be installed following the outline of the enclosing wall, to a height of at least 30 mm and with a minimum overlap of 100mm using a suitable tape to seal seams. After finishing, the barrier must cover the entire subflboor area without any gaps. Never mechanically secure the barrier with screws, nails or staples as this may compromise its effectiveness.

# 3. INSTALLATION OF THE UNDERLAY

Place one roll of the underlay parallel to the wall and in the opposite direction you plan to install the final floor to reduce seams. Cut the underlay material roll to the desired length and install it directly, covering the entire surface of the room. The underlay must cover the entire area without any gaps, and be securely joined using duct tape. Never mechanically secure the underlay with screws, nails or staples as this may compromise its effectiveness. Install the flooring perpendicularly to the underlay. Always follow the flooring manufacturer's recommended installation instructions.

#### 4. GLUED DOWN INSTALLATION

Before installing the underlay, apply the glue and make sure that the surface has been treated to prevent moisture. the installation of a moisture barrier is not necessary. After applying the glue, cut the underlay material roll to the desired length and install it directly, covering the entire surface. The underlay must cover the entire area without any gaps, and be securely joined using duct tape. Never mechanically secure the underlay with screws, nails or staples as this may compromise its effectiveness. Apply glue on the underlay and install the flooring perpendicularly to the underlay. Always follow the flooring manufacturer's recommended installation instructions.

#### **APPLICATION PROCESS**

#### **GLUED DOWN INSTALLATION**









- 1. Installation of perimeter barrier; 2. Installation of underlay (glued);
- 3. Installation of final flooring (glued); 4. Cutting perimeter barrier.

#### FLOATING INSTALLATION















1. Installation of the moisture barrier; 2. Installation of the tape on the seams; 3. Installation of perimeter barrier; 4. Installation of underlay; 5. Installation of the tape on joints between rolls; 6. Installation of final flooring; 7. Cutting perimeter barrier.









The data provided in this Material Data Sheet represents typical values. This information is not intended to be used as a purchasing specification and does not imply suitability for use in a specific application and lose not imply suitability for use in a specific application and lose not imply suitability for septiments. Amorim Cork Solutions regarding specific application recommendations. Amorim Cork Solutions expressly disclaims all warranties, including any implied warranties or merchantability or of fitness for a particular purpose. Amorim Cork Solutions is not liable for any indirect special, incidental, consequential, or punitive damages as a result of using the information listed in this MDS. Any of its material specification sheets, its products or any future use or re-use of them by any person or entity. For contractual purposes, please request our Product Specifications Sheet (PDA).

www. amorim cork solutions. com